

1. 6an Male to 5/16" SAE Quick-Disconnect Female Push-On EFI Fitting (2) – for OEM feed and return hard lines to allow for 6AN PTFE hose connection.
2. 6an to 8an ORB Fuel Rail Fittings (4) - For fuel rail inlets/outlets.
3. 6an to 6an ORB FPR Fittings (3) - for FPR Inlet/Outlet.
4. M8-1.25 x 16 Hex Flange Bolt (1) - "L" bracket to block bolt.
5. M6 x 16 Zinc Hex Flange Bolt (2) - FPR bracket to shock tower bolts.
6. 3.5mm ID Vacuum Hose (2') - FPR to IM vacuum.
7. Zip Ties (2) - to secure both ends of FPR vacuum hose on fittings.

